



But, it is not just the water that is the problem. The water is also a problem because it is so much water. It is so much water that it is a problem. It is so much water that it is a problem. It is so much water that it is a problem.

Without surface-water drainage, frequent flooding creates many problems:

- It is a problem because it is so much water.
- It is a problem because it is so much water.
- It is a problem because it is so much water.

Flooding can occur where drains are:

- It is a problem because it is so much water.
- It is a problem because it is so much water.
- It is a problem because it is so much water.

?

- It is a problem because it is so much water.
- It is a problem because it is so much water.
- It is a problem because it is so much water.

D It is a problem because it is so much water.

I It is a problem because it is so much water.

?

D It is a problem because it is so much water.

- It is a problem because it is so much water.
- It is a problem because it is so much water.
- It is a problem because it is so much water.



At what point?

At the point where the curve crosses the x-axis, i.e. where $y = 0$.

At the point where the curve crosses the y-axis, i.e. where $x = 0$.

At the point where the curve crosses the x-axis, i.e. where $y = 0$.

At the point where the curve crosses the y-axis, i.e. where $x = 0$.

At the point where the curve crosses the x-axis, i.e. where $y = 0$.


At the point where the curve crosses the y-axis, i.e. where $x = 0$.

At the point where the curve crosses the x-axis, i.e. where $y = 0$.


At the point where the curve crosses the y-axis, i.e. where $x = 0$.

At the point where the curve crosses the x-axis, i.e. where $y = 0$.





تحت إشراف
مديرية التعليم
بمحافظة
المنيا
المنيا
المنيا



تحت إشراف
مديرية التعليم
بمحافظة
المنيا
المنيا
المنيا

تحت إشراف
مديرية التعليم
بمحافظة
المنيا
المنيا
المنيا

